

BIG

BM HD 110

Controlling via DIP-switches

<u>Function:</u>		DIP 1	DIP 2	DIP 3	DIP 4	DIP 5	DIP 6	DIP 7	DIP 8	DIP 9	DIP 10
DMX-Mode		×	×	×	×	×	×	×	×	×	1
Slave-Mode		0	0	0	0	0	0	0	0	0	1
Master-Mode	Sound Mode	0	0	0	0	0	0	0	1	0	0
	Auto Mode	×	×	×	1	1	1	1	0	0	0
	Strobe	×	×	×	1	0	0	0	0	0	0
	Fade	×	×	×	0	1	0	0	0	0	0
	Color-change	×	×	×	0	0	1	0	0	0	0
	Cross-fade	×	×	×	0	0	0	1	0	0	0
	RED	1	×	×	0	0	0	0	0	0	0
	GREEN	×	1	×	0	0	0	0	0	0	0
	BLUE	×	×	1	0	0	0	0	0	0	0
	LED Speed 1	1	1	×	×	×	×	×	×	×	0
LED Speed 2	0	1	×	×	×	×	×	×	×	0	
LED Speed 3	1	0	×	×	×	×	×	×	×	0	
LED Speed 4	0	0	×	×	×	×	×	×	×	0	

1=on 0=off ×=changeable

DMX-protocol

Channel:	Value:	Feature:
1	000 – 255	Red (0 – 100%)

Channel:	Value:	Feature:
2	000 – 255	Green (0 – 100%)

Channel:	Value:	Feature:
3	000 – 255	Blue (0 – 100%)

Channel:	Value:	Feature:
4	000 – 255	Master Dimmer or Increasing speed

Channel:	Value:	Feature:
5	000 – 000	ON
	001 – 020	Fade
	021 – 040	Color-change
	041 – 060	ON
	061 – 255	Strobe (increasing)